

# Factory default settings VIP G2

## for multi-channel use

Digital Audio Out	→	Dolby Digital Out	→	Dolby Digital
	→	DTS Out	→	DTS Out
	→	Linear PCM Out	→	Down Sample Off
	→	MPEG Out	→	MPEG > PCM
Video Output	→	TV Screen	→	16:9 (Wide)
	→	Component Out	→	progressive
	→	AV Connector	→	RGB
	→	S-Video Out	→	S2
	→	Still Picture	→	Auto
Language	→	Audio Language	→	English
	→	Subtitle Language	→	English
	→	Auto Language	→	On
	→	Subtitle Display	→	off
Display	→	OSD Language	→	English
	→	On Screen Display	→	On
	→	Angle Indicator	→	On
	→	Background	→	Logo
	→	Screen Saver	→	Off
Options	→	Parental Lock	→	Off
	→	Bonus Group	→	
	→	Auto Disc Menu	→	On
	→	Group Playback	→	Single
	→	DVD Playback Mode	→	DVD-Audio
	→	SACD Playback	→	Multi-ch Area
	→	HDMI Settings	→	...
	→	CD Playback	→	PCM Playback
	→	DTS Downmix	→	Stereo
Speakers	→	Audio Out	→	5.1 Channel
	→	Speaker Installation	→	all set to "LARGE / On"
	→	Speaker Distances	→	...
	→	Channel Level	→	Fix